

Key	Part #	Description
A	ML-Sensor carriage pin-MP	Sensor carriage pin
B	See Head A25 Sensor Carriage Assy	Sensor carriage & Lid Assy
C	OR-042 SC bottom	O-ring silicone, goes between sensor carriage lid and body
D	FST-Screw ML	Screw for lid SS Philips
E	ML-Solenoid base-MP	Solenoid base

